


Mid-West®

Instrument



Model 120 Series "Filter Minder" Installation and Operating Instructions





INSPECTION

Before installation check the nameplate on each instrument against the receiving paperwork and the intended application for correct part number, materials of construction, working pressure, dial range, etc. If equipped with switches, check electrical rating, type of enclosure, etc. Inspect for shipping damage and, if damaged, report it immediately.

NOTE - Before attempting repairs contact your local Mid-West Representative or our factory. Failure to do so will void any warranty.

PRODUCT DESCRIPTION

The Model 120 Series "Filter Minder" is a rugged, medium-range differential pressure instrument available as a switch, a gauge, or both. See "Part Numbering System". (Fig. 4) for available options.

Differential pressure is sensed by the movement of a floating piston magnet against a calibrated spring. The magnetically coupled gauge pointer outside the pressure housing follows the movement of the piston magnet and indicates differential pressure on the dial scale.

When equipped with switches, a contact is made or broken by the magnetic field of the piston magnet. See Bulletin ELECIM120/latest for gauges with switches.

The unit provides full over-range protection to the rated working pressure of the housing in either direction.

The precise piston/bore fit allows minimal leakage from high to low sides. This leakage is only 5 to 15 SCFH air at ambient conditions and a pressure differential of 100 PSID.

INSTALLATION

Model 120 Series "Filter Minder" is calibrated and tested prior to shipment and is ready for immediate installation. Use of the following installation procedures should eliminate potential damage and provide optimum trouble-free operation.

1. CONNECTIONS

1/4" FNPT are provided as standard but check paperwork for connections ordered. There are two connections on the housing identified as "hi" and "lo" for high pressure and low pressure (Fig. 2). Be sure these get plumbed to the proper connections on your system. Improper connection will not damage the instrument, but it will not function properly. Flexible tubing is recommended to minimize the effect of any vibration that may exist.

2. INSTRUMENT LOCATION

On liquid service the instrument should be mounted **below** the process connections to facilitate self-bleeding. On gas service it should be located **above** the process connections to promote self-draining. If the process contains particulates, a "pigtail" loop or drop leg (manometer "U-tube" configuration) in the tubing will minimize the possibility of it migrating into the instrument.

3. PANEL MOUNTING

Gauges with 2-1/2" dials can **only** be mounted through the **rear** of the panel. Make the proper panel cutout as indicated in (Fig.1). Remove the (4) bezel screws. Insert the gauge front through the rear of the panel and reinstall the bezel screws through the **front** of the panel and into the gauge bezel. Tighten the screws securely, alternating in a **diagonal** pattern.

Gauges with 3-1/2" dial should be mounted from the front of the panel. Contact factory for mounting information and dimensional data.


Gauges with 4-1/2" dial should be mounted from the **front** of the panel. Make the cutout as indicated in (Fig. 1). Insert the (4) panel mounting studs, finger tight, into the metal inserts located in the rear of the bezel. Insert the gauge through the panel, aligning the panel mounting studs with the holes in the panel. Install the (4) #8-32 nuts onto the studs and tighten securely.

4. PIPE MOUNTING

An optional pipe mounting kit is available for mounting the gauge to a 2" vertical or horizontal pipe (Fig. 3).

TROUBLE SHOOTING

- 1. Gauge does not indicate differential.
 - A. Check for proper hook up, high to "hi" and low to "lo".
 - B. Make certain block valves are open and, if using a 3-valve manifold, that the equalizer (balance) valve is closed.
 - C. If A & B check out correctly, loosen or disconnect the high pressure line to determine if there is pressure to the instrument.
 - D. If there is pressure to the instrument, check to determine that there is differential across the unit being monitored. If so, contact the factory for assistance and/or an "RGA" (return goods authorization) number to return the instrument for repair or replacement.




Supplementary 120 Dimensional/Mounting Data MODEL 120 PORTS (BACK VIEW) 1/4 F.N.P.T. PROCESS CONNECTIONS _2.12<u>_</u> (53.8) OPT'L END CONNECTIONS STANDARD __4.91_ (124.7) L 4.25 (107.9) OPT'L REVERSED END CONNECTIONS OPT'L REVERSED BACK CONNECTIONS (Fig. 2) TYPICAL 2" PIPE MOUNTING (BACK CONNECTIONS ONLY) 3.75 (95) FOR 2-1/2 INCH DIAL 4.18 (106.1) FOR 4-1/2 INCH DIAL TYPICAL WALL MOUNTING 4-1/2 INCH DIAL (BACK OR END CONNECTIONS) $\qquad \qquad \begin{array}{c} -21 \text{ Dia. 8 Places} \\ (5.3) \end{array}$ TYPICAL WALL MOUNTING 2-1/2 INCH DIAL (END CONNECTION OPTION ONLY) 6.25 <u></u> (158.7) - 3.75 -(95.2) 9.12 (231.6) 10.12 (257.0) 4.75 (120.7) 5.37 (136.4) _ 4.60 _ (116.8) (Fig. 3)

- NOTES: 1. Drawings show standard gauge nominal dimensions. (not to scale)
 - 2. Dimensions shown in parentheses are in millimeters.
 - 3. Manufacturer reserves the right to change specifications without prior notice.

Standard Model Specifications

120-AA-00-OO 6000 P.S.I.G. Working Pressure Aluminum Body, Stainless Steel Piston, Ceramic Magnets, Buna N Seals, 2 1/2" Engineering Plastic Case with Shatter-Resistant Lens. 1/4" FNPT Back Connections. Accuracy ±3-2-3% Full Scale (Ascending).

Part Numbering System:



- configurations options L & M
- F. Pipe mounting kit (carbon steel) not available w/C ,D, E or F electrical switch options
- G. Pipe mounting kit (stainless steel) (no back or bottom connections for C, D, E or F electrical switch options)

NOTE: Not all options available in combination with other options.

NOTE: Factory preset switches at no charge (specify setting)

NOTE: The use of diaphragm seals is not recommended for Model 120 series gauge. Attempts to install such seals on this gauge will void the warranty. Manufacturer reserves the right to change specifications without prior notice. PROOF PRESSURE: 12,000 PSI for models 120A and 120S. 10,000 PSI for models 120M and 120N.

Mid-West Instrument, 6500 Dobry Dr., Sterling Heights, MI 48314 Tel: 586-254-6500 Fax: 586-254-6509 www.midwestinstrument.com

Temperature Limits: -40°F(-40°C) to +200°F(+93°C) These limits are based on the entire instrument being saturated to these temperatures. System (process) temperatures may exceed these limitations with proper installation. Contact our customer service representative for details. **STANDARDS**: All model 120 Series differential pressure gauges either

conform to and/or are designed to the requirements of the following standards: **ASME B1.20.1** NACE MR0175

ASMF B40.100

NEMA Std. No. 250 SAE J514

Groups E, F & G.

(3)5000 PSIG SWP for Stainless Steel; 3000 PSIG SWP for Aluminum.

CSA-C22.2 No. 14.25 and 30 EN-61010-1

UL Std. No. 50,508 and 1203